


Ferrule Support Chairs



Description



An easy-to-use ferrule chair developed to locate “face-up” ferrules in precast panels and tilt-up panels. This chair is designed to locate the (ferrule with antennae cap) to about 1 or 2mm below the panel surface when a 96mm ferrule is used.

A major time saver – the ferrule chair is manufactured to provide a strong, impact resistant support which is non-corrosive and having minimal exposure.




Size Availability

Available to suit a 96mm ferrule for panel thicknesses of 125, 150, 175 and 200mm

Ideal for:

- The Tilt Panel Industry

Ferrule Support Chairs



DIMENSIONS

PRODUCT CODE	A	B	Qty per Bag	Mass Per Bag Kg
FWSC 125/96	96	125	50	4.3
FWSC 150/96	96	150	50	4.5
FWSC 175/96	96	175	50	5.5
FWSC 200/96	96	200	50	6.4

* Antenna Cap located with 1 to 2mm clearance for screeding.

All dimensions are nominal and expressed in mm.

Note: Other ferrule lengths and widths can be accommodated subject to volume and timing.

